

... for more than 40 years +

KRASO®

SIMPLE + TIGHT

All rights to the drawings and designs are the property of KRASO GmbH & Co. KG. •
Copying and distribution of the drawings as well as any other use require our written consent. •



KRASO® Sealing Insert Type IN-GR® - split - Installation instructions



KRASO GMBH & CO. KG
Baumannweg 1 | DE-46414 Rhede
T +49(0)28 72 - 95 35-0
info@kraso.de | **KRASO.de**

1.7-MA.EN-v1.0-03.26-RSc.DK



The **KRASO®** Sealing Insert Type IN-GR® - split - can also be used as a blind plug.

KRASO® Sealing Insert Type IN-GR® - split -

Inner seal for cable protective hoses Type-R / corrugated pipes for the installation of one or several media lines | DafStB waterproof concrete guideline: stress class 1 + 2

1. Measure the media line.
2. Open the **KRASO®** Sealing Insert Type IN-GR® - split - and remove the plug. Measure the opening at its narrowest point and compare it with the media line.
3. If the opening for the media line is too small, push the rubber ring out to the rear by hand and cut it. Repeat the process if necessary.
4. Push the **KRASO®** Sealing Insert Type IN-GR® - split - around the media line.
5. Close the **KRASO®** Sealing Insert Type IN-GR® - split -.
6. Insert the **KRASO®** Sealing Insert Type IN-GR® - split - into the protective hose.
7. Tighten the Torque Control Nuts **KRASO®** DKM crosswise step by step. Tighten the Torque Control Nuts **KRASO®** DKM until you hear a "click".

