

... for more than 40 years +

All rights to the drawings and designs are the property of KRASO GmbH & Co. KG. •
Reproduction and distribution of the drawings as well as any other use require our written consent. •




KRASO GMBH & CO. KG
Baumannweg 1 | DE-46414 Rhede
T +49 (0) 28 72 - 95 35 - 0
info@kraso.de | **KRASO.de**

5.5-MA.EN-v1.0-08.25-RSc.DK

KRASO[®]

SIMPLE + TIGHT



KRASO[®] Universal Funnel

Installation instructions



KRASO® Universal Funnel

For the connection of displaced KG/HT pipes and for the connection to KG/KG 2000 lines, with one-sided spigot, walkable building period protective cover. Optionally available: screwable **KRASO® Stainless Steel Clamping Flange** for the connection to non-adhesive foils | **DafStB waterproof concrete guideline: stress class 1 + 2, DIN 18533 W1-E**

1. Top edge sleeve = TEUF minus 16 cm. TEUF = top edge unfinished floor.
 2. Apply lubricant to the **KRASO® Universal Funnel** and insert into the main pipe.
 3. Insert support cages and upper reinforcement. Top edge **KRASO® Universal Funnel** = TEUF. If necessary: Fix the **KRASO® Universal Funnel** to the upper reinforcement.
 4. Concrete base plate.
- Installation situation without vapour barrier:**
5. If no bonding is carried out, remove the building period protective cover. Clean lip ring and funnel.
 6. Apply lubricant to the bends (2 x 15° / 30° / 45°) and insert into the **KRASO® Universal Funnel**.
- Installation situation with vapour barrier:**
7. Tape off the base plate. Apply the sealing sheet according to the manufacturer's instructions.
 8. Remove the walkable building period protection cover. Clean lip ring and **KRASO® Universal Funnel**.
 9. Apply lubricant to the bends (2 x 15° / 30° / 45°) and insert into the **KRASO® Universal Funnel**.

