

... for more than 40 years +

KRASO[®]

SIMPLE + TIGHT



All rights to the drawings and designs are the property of KRASO GmbH & Co. KG. •
Reproduction and distribution of the drawings as well as any other use require our written consent. •




KRASO[®] Fibre Cement Casing

Installation instructions



KRASO GMBH & CO. KG
Baumannweg 1 | DE-46414 Rhede
T +49(0) 28 72 - 95 35 - 0
info@kraso.de | **KRASO.de**

5.28-MA.EN-v1.0-08.25-RSc.DK



KRASO® Fibre Cement Casing

For the installation in waterproof concrete walls for installation of pipes or cables using sealing inserts (not included in the scope of supply)

| DafStB waterproof concrete guideline: stress class 1 + 2

1. Nail down the **KRASO®** Installation/Formwork Aid using a hammer.
2. Lay the reinforcement.
3. Place the **KRASO®** Fibre Cement Casing onto the **KRASO®** Installation/Formwork Aid.
4. If necessary: fix the **KRASO®** Fibre Cement Casing to the reinforcement.
5. Close the **KRASO®** Fibre Cement Casing using the **KRASO®** Installation/Formwork Aid.
6. Formwork and ensure sufficient distance from the tie points.
7. Concrete the wall. To prevent segregation in the area of the penetration, the free fall height of the concrete must not exceed 1 m. *
8. Remove formwork.

